

COMPACT. POWERFUL.

VMAC UNDERHOOD70 APPLICATION LIST



Engine	Chassis (Notes)	Model Year	Truck Options	Part #	Adapter Kit Required	Tools Required
FORD APPLICATIONS						
6.7L Power Stroke V8 Diesel	F250-F550 SuperDuty	2012 - 2011	W/WOAC, W/OVBO	V900120		
6.4L Power Stroke V8 Diesel	F250-F550 SuperDuty	2010 - 2008	WODA, W/WOAC, W/OVBO (WILL NOT FIT DUAL ALTERNATOR UNLESS CONVERTED TO SINGLE ALTERNATOR SYSTEM - CALL FOR INFO)	V900110		5900219
6.0L Power Stroke V8 Diesel	F250-F550 SuperDuty	2007 - 2005	WODA, W/WOAC, W/OVBO (WILL NOT FIT DUAL ALTERNATOR UNLESS CONVERTED TO SINGLE ALTERNATOR SYSTEM - CALL FOR INFO)	V900080	A900002	5900083 & 5900094
		2004 - 2003.25			A900001	
6.8L Triton V10 Gas	F450-F550 SuperDuty	2012 - 2011	W/WOAC	V900111		5900245
	F250-F550 SuperDuty	2010 - 2008	W/WOAC	V900101		
		2007 - 2005		V900081		
6.2L V8 Gas	F250-F550 SuperDuty	2012	W/WOAC	V900112		
		2012 - 2011				
5.4L Triton V8 Gas	F250-F550 SuperDuty Mfg after Sep 26/07	2010 - 2008	W/WOAC	V900102		
	F250-F550 SuperDuty Mfg up to Sep 26/07	2008		V900092		
GM APPLICATIONS						
6.0L Vortec V8 Gas	C/K2500HD Pickup RPO Code L96 and E63	2012	W/WOAC, WOJL1 **RPO Codes located in Glovebox	V900127		
	C/K1500 Pickup	2012-2011	W/WOAC, WOXY	V900115		
	C/K2500HD Pickup Box Delete RPO Code L96 and ZW9	2012	W/WOAC, WOJL1 **RPO Codes located in Glovebox	TBD		
	C/K3500HD Pickup and Cab Chassis	2012	W/WOAC, WOJL1	TBD		
	C/K2500HD-C/K3500HD	2011	W/WOAC, WOJL1	V900117		
	C/K2500HD-C/K3500HD 8th digit "G" in VIN Number	2010 - 2007	W/WOAC, WOJL1, WJL1* (*Use adaptor kit)	V900108	*A900007	
C/K2500HD-C/K3500HD GMT900 8th digit "K" in VIN Number Reg/Ext Cab Mfg after Feb 4/07; Crew Cab Mfg after Mar 25/07; Dually Mfg after April 29/07						
6.6L Duramax V8 Diesel	C/K2500HD-C/K3500HD	2012 - 2011	W/WOAC, WODA, W/WOVP (WILL NOT FIT DUAL ALTERNATOR UNLESS CONVERTED TO SINGLE ALTERNATOR SYSTEM - CALL FOR INFO)	V900113		5900010 & 5900076
	C/K2500HD-C/K3500HD GMT900 Reg/Ext Cab Mfg after Feb 4/07; Crew Cab Mfg after Mar 25/07; Dually Mfg after April 29/07	2010 - 2007		V900103		
	C/K2500HD-C/K3500HD Reg/Ext Cab Mfg up to Feb 4/07; Crew Cab Mfg up to Mar 25/07; Dually Mfg up to April 29/07	2007 "Classic" - 2006		V900093		
	C4500-C5500 (FAMILY 2) Mfg after Feb 4/07	2009 - 2007		V900099		
	C4500-C5500 (FAMILY 2) Mfg up to Feb 4/07	2007 "Classic" - 2006		V900098		
DODGE / RAM APPLICATIONS						
6.7L Cummins 24V Inline 6 Diesel	2500-3500 Chassis Cab & 4X4 PICK UP	2012 - 2010	CCO, WAC (WOAC - CALL FOR INFO; WILL NOT FIT 4x2 PICK UP TRUCK)	V900114		5900220
		2009 - 2007		V900104		
	4500-5500 Chassis Cab	2012 - 2011	WAC	V900116		
		2010 - 2008	(WOAC - CALL FOR INFO)	V900106		5900220
5.9L Cummins 24V Inline 6 Diesel	2500-3500	2009 - 2007	W/WOAC	V900094		
INTERNATIONAL APPLICATIONS						
MaxForce 7	Class 4/5 TerraStar For ease of installation, order truck with VMAC Prep Kit. Call VMAC for details.	2012	4x2 (4x4 - CALL FOR INFO)	V900109		
STERLING APPLICATIONS						
6.7L Cummins 24V Inline 6 Diesel	4500-5500 Chassis Cab	2009 - 2007	WAC (WOAC - CALL FOR INFO)	V900106		5900220

LEGEND

WAC/WOAC = With/Without Air Conditioning	SC = Confirmed Single Cab Only, For Double Cab Call for Details	5900010 = Crank Locking Tool	5900219 = Water Pump Wrench
WVP/WOVP = With/Without Vacuum Pump	WOJL1 = Without RPO code JL1 (trailer brake controller)	5900076 = Crank Pin Removal Tool	5900220 = Fan Countersink Tool
WDA/WODA = With/Without Dual Alternators	WOVBO = Without Vacuum Brake Option	5900083 = A/C Bending Tool	5900245 = A/C Bending Tool
WOHY = Without Hybrid			
CCO = Chassis Cab and 4x4 Pick Up Truck Only. Will not fit 4x2 Pick Up Truck.		5900094 = Fan Wrench	

The above specifications are subject to change without notice.

Contact your local dealer for further information or contact VMAC at:

Toll Free: 1-800-738-8622
Web: www.underhoodair.com